Occupational Sat	fety and		ninistration		
MATERIAL	SAFE	TY DAT	A SHEET		
Required under USDL Safet Shipbuilding, and Sh	y and He	ealth Regulating (29 CFR	ions for Ship Repair 1915, 1916, 1917)	ng,	
***Section I – Produc				n***	
Manufacturer's Name		<b>p</b>	Emergency Tel		
Master Industries, Inc.				(714) 660-0644	
Address (Number, Street, City, State, and Zip Code)	0.0.00	-	Date Issued: 0	2/26/2010	
14420 Myford Road, Bldg.150 Irvine, California Chemical Name and Synonyms			d Synonyms		
Polymeric diphenylmethane diisocyanate	Trau			LR (HCNO 65D-180S-T	AN A COMP)
Chemical Filially	Form		<i><sup>2</sup></i> <sup>2</sup> <sup>1</sup>		·
***Section II – Hazardous	Ingre	edients/S	ARA II Inform	nation***	
Reportable Components	81 0		CAS Number	Vapor Pressure	Weight %
				mmHg @ Temp	-
*Polymeric diphenylmethane diisocyanate ACGIH TLV: 0.005ppm TLV; OSHA CLV: 0.02	2ppm, 0.	.2mg/m <sup>3</sup>	9016-87-9	<0.00001 @ 25°C	65-70%
Diisodecyl phthalate			68515-49-1	0.000 @ 68°F	25-30%
* Indicates toxic chemical(s) subject to the reporting requiren	nonte of	faction 21	2 of Title III and	of 40 CED 272	
* indicates toxic chemical(s) subject to the reporting requirem	nems of	section 51	5 of Thie III and	01 40 CFR 572.	
California Proposition 65 Information					
Warning: Detectable amounts of chemical(s) known to	the Sta	ate of Calif	ornia to cause can	cer in lab animals are pr	resent in this
product.					
***Section III –				1 1 4 2	
Boiling Range406°F - 491°FVapor Pressure (mm Hg)Heavier than air.		Specific G Evaporati	ravity (H2O=1)	1.142 Slower than eth	)er
Coating V.O.C. 0.0 lb/gl		Material V		0.0 lb/gl	
				U	
Solubility in Water Not soluble in water. Reacts	s slowly	with wate	r to liberate CO2	gas and heat.	
Appearance and OdorLiquid, hydrocarbon odor.					
***Section IV – Fire	and L	Typlogia	Hazard Data	***	
Flash Point (Method Used): 390°F (PMCC) Flammable		-	ower: 0.3%	Upper: N	V/A
Extinguishing Media	Linnts.	• L	0wer. 0.3 /0	Opper. 1	VA
Small Fire: Use dry chemical powder. Large Fire:	Use wat	ter sprav. f	or or foam.		
Special Fire Fighting Procedures					
Do not use water jet. Protective clothing for fire: Sp		oggles, full	suit, gloves. Self	contained breathing app	paratus
(SCBA) should be used to avoid inhalation of produ	ict.				
Unusual Fire and Explosion Hazards	which	no or matu	a alagad contains	This resultion secolor	notes at higher
Reacts slowly with water to produce carbon dioxide temperatures. Cool closed drums with water mist.					
and can be dangerous. DO NOT pressurize, out, we					
sparks, static electricity, or other sources of ignition					
Empty drums should be completely drained, properl					
disposed of.					
	<b>V</b>	0004:	Doto***		
***Section	$\mathbf{v} - \mathbf{R}\mathbf{e}$	eactivity	Data		
Stability Stable at room temperatures. Contact with moisture	e. other	materials t	hat react with isoc	vanates, or temperatures	s above
350°F (177°C), may cause polymerization.	.,			j	
Conditions to Avoid					
Avoid high temperatures. Avoid freezing.					

Incompatibly (Materials to Avoid)
Avoid copper alloys. This product will react with any material containing active hydrogen such as water, alcohol, amines,
bases, acids, and any other compounds meant to react with isocyanates. The reaction with water is very slow under 50°C
(122°F) but is accelerated at higher temperatures. Some reactions may be violent.
Hazardous Decomposition or Byproducts
By Fire and High Heat: Carbon Dioxide (CO2), carbon monoxide (CO), oxides of nitrogen (NOx), dense black smoke,
Hydrogen cyanide, isocyanic acid, other undetermined compounds.
Hazardous Polymerization
Polymerization may occur at elevated temperatures in the presence of water, alkalis, tertiary amines and metal compounds.
***Section VI – Health Hazard Data***
<b>WARNING</b> : This product is intended to be used as a two-component system. The mixing of these two components (part A and part B)
will have hazards associated with both part A and part B. Refer to the MSDS of each for complete hazard information when
working with the mixture.
working with the mixture.
Inhelation Health Dicks and Symptoms of Exposure
Inhalation Health Risks and Symptoms of Exposure
Inhalation at levels above the occupational exposure limit could cause respiratory sensitization and risk of serious damage to the
respiratory system. The onset of respiratory symptoms may be delayed for several hours after exposure. A hypersensitive
response to even minimal concentrations of diisocyanates may develop in sensitized persons.
Inhalation symptoms: Diisocyanate vapors or mist at concentrations above the TLV or PEL can irritate (burning sensation) the
mucous membranes in the respiratory tract (nose, throat, lungs) causing runny nose, sore throat, coughing, chest discomfort,
shortness of breath and reduced lung functions (breathing obstruction). Persons with a preexisting, nonspecific bronchial
hypersensitivity can respond to concentrations below the TLV or PEL with similar symptoms as well as asthma attack or asthma-
like symptoms. Exposure above the TLV or PEL may lead to bronchitis, bronchial spasm and pulmonary edema (fluid in the
lungs), chemical or hypersensitivity pneumonia, with flu-like symptoms (e.g. fever, chills) has also been reported. These
symptoms can be delayed up to several hours after exposure. These effects are usually reversible.
Chronic inhalation: As a result of previous repeated overexposure or a single large dose, certain individuals may develop
Sensitization to diisocyanates (asthma or asthma-like symptoms) that may cause them to react to a later exposure to
diisocyanates at levels well below the TLV or PEL. These symptoms, which can include chest tightness, wheezing, cough,
shortness of breath and asthma attach, could be immediate or displayed up to several hours after exposure. Extreme asthmatic
reactions can be life threatening. Similar to many nonspecific asthmatic responses, there are reports that once sensitized an
individual can experience these symptoms upon exposure to dust, cold air or other irritants. This increased lung sensitivity
can persist for weeks and in severe cases for several years. Sensitization can be permanent. Chronic overexposure to
diisocyanates has also been reported to cause lung damage (including fibrosis, decrease in lung function) that may be permanent.
Skin and Eye Contact Health Risks and Symptoms Exposure
Skin: Acute Skin: Causes irritation with symptoms of reddening, itching, and swelling. Persons previously sensitized can
experience allergic reactions and symptoms of reddening, itching, and rash. Cured material is difficult to remove. Contact with
isocyanates can cause discoloration.
Skin: Chronic Skin: Prolonged irritation can cause reddening, swelling, rash, and in some cases, sensitization. Animals tests
on isocyanates indicate that skin contact alone may lead to an allergic respiratory reaction.
Eye: Acute Eye: Causes irritation and symptoms of reddening, tearing, stinging and swelling. May cause temporary corneal
injury. Vapor or aerosol may cause irritation with symptoms of burning and tearing.
Skin Absorption Health Risks and Symptoms of Exposure
Animal tests have indicated that respiratory sensitization may result from skin contact with isocyanates. Experience indicates
that direct skin contact is the route of exposure most likely to cause sensitization.
Ingestion Health Risks and Symptoms of Exposure
May cause irritation; symptoms may include abdominal pain, nausea, vomiting, and diarrhea.
Health Hazards (Acute and Chronic)
Inhalation (acute): Irritation of respiratory tract, sensitization, lung damage.
Inhalation (chronic): Sensitization, lung damage.
Carcinogenicity: NTP, Carcinogen: No, IARC Monographs: No, OSHA Regulated: No
Specific Health Risks
Respiratory sensitizer

Medical Conditions Generally Aggravated by Exposure
Skin allergies, eczema, asthma, respiratory disorders. All applicants who are assigned to an isocyanate work area should undergo
a pre-placement medical evaluation. A history of eczema or respiratory allergies such as hay fever, are possible reasons for
medical exclusion from isocyanate areas. Applicants who have a history of adult asthma should be restricted from work with
isocyanates. A comprehensive annual medical surveillance program should be instituted for all employees who are
potentially exposed to diisocyanates. Once a worker has been diagnosed as sensitized to any isocyanate, no further exposure can
be permitted.
be permitted.
Emergency and First Aid Procedures
Eye Contact: In case of contact, immediately flush eyes with plenty of water for at least 15 minutes. Use lukewarm water if
possible. Use fingers to ensure that eyelids are separated and that the eye is being irrigated. Get medical attention.
<b>Skin Contact</b> : Immediately remove contaminated clothing and shoes. Wash off with soap and water. Use lukewarm water is
possible. Wash contaminated clothing before reuse. For severe exposure, immediately get under safety shower and begin rinsing.
Get medical attention if irritation develops. After washing, cover affected area with polyethylene glycol (300-500 molecular
weight) and wash again immediately with soap and water to thoroughly remove polyethylene glycol and residual isocyanate.
Repeat if necessary.
<b>Inhalation:</b> Move to an area free from further exposure. Get medical attention immediately. Administer oxygen or artificial
respiration as needed. Asthmatic symptoms may develop and may be immediate or delayed up to several hours. Extreme
asthmatic reaction can be life threatening.
<b>Ingestion</b> : Do NOT induce vomiting. Wash mouth out with water. Do not give anything by mouth to an unconscious person.
Get medical attention.
Note to a Physician:
Eyes: Stain for evidence of corneal injury. If cornea is burned, instill antibiotic/steroid preparation as needed. Workplace
vapors could produce reversible corneal epithelial edema impairing vision.
Skin: This compound is a skin sensitizer. Treat symptomatically as for contact dermatitis or thermal burn.
Ingestion: Treat symptomatically. There is no specific antidote. Induced vomiting is contraindicated because of the irritating
nature of the compound.
Inhalation: Treatment is essentially symptomatic. An individual having a derma or pulmonary sensitization reaction to this
material should be removed from further exposure to any diisocyanate.
***Section VII – Precautions for Safe Handling and Use***
***Section VII – Precautions for Safe Handling and Use*** Steps to be Taken in Case Material is Released or Spilled
Steps to be Taken in Case Material is Released or Spilled
Steps to be Taken in Case Material is Released or Spilled         Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water
Steps to be Taken in Case Material is Released or Spilled Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on
Steps to be Taken in Case Material is Released or Spilled         Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil.
Steps to be Taken in Case Material is Released or Spilled         Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil.         Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate
Steps to be Taken in Case Material is Released or Spilled         Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil.         Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head
Steps to be Taken in Case Material is Released or Spilled         Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil.         Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent
Steps to be Taken in Case Material is Released or Spilled         Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil.         Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose.
Steps to be Taken in Case Material is Released or Spilled         Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil.         Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent
Steps to be Taken in Case Material is Released or Spilled         Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil.         Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape.
Steps to be Taken in Case Material is Released or Spilled         Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil.         Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape.         Additional Spill Procedures/Neutralization/Decontamination – Neutralization/Decontamination Solutions:
Steps to be Taken in Case Material is Released or Spilled         Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil.         Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape.         Additional Spill Procedures/Neutralization/Decontamination – Neutralization/Decontamination Solutions: <ul> <li>Colorimetric Laboratories Inc. (CLI) decontamination solution.</li> </ul>
Steps to be Taken in Case Material is Released or Spilled         Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil.         Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape.         Additional Spill Procedures/Neutralization/Decontamination – Neutralization/Decontamination Solutions: <ul> <li>Colorimetric Laboratories Inc. (CLI) decontamination solution.</li> <li>A mixture of 75% water, 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10) and 5% n-propanol.</li> </ul>
<ul> <li>Steps to be Taken in Case Material is Released or Spilled         <ul> <li>Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil.</li> </ul> </li> <li>Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape.</li> <li>Additional Spill Procedures/Neutralization/Decontamination solution.</li> <li>Colorimetric Laboratories Inc. (CLI) decontamination solution.</li> <li>A mixture of 75% water, 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10) and 5% n-propanol.</li> <li>A mixture of 80% water, and 20% non- ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10).</li> </ul>
<ul> <li>Steps to be Taken in Case Material is Released or Spilled Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil. </li> <li>Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape. Additional Spill Procedures/Neutralization/Decontamination solution. 2. A mixture of 75% water, 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10) and 5% n-propanol. 3. A mixture of 80% water, and 20% non- ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10). 4. A mixture of 90% water, 3-8% ammonium hydroxide or concentrated ammonia, and 2% liquid detergent.</li></ul>
<ul> <li>Steps to be Taken in Case Material is Released or Spilled Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil. </li> <li>Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri<sup>TM</sup>, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape. Additional Spill Procedures/Neutralization/Decontamination solution. <ol> <li>A mixture of 75% water, 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10) and 5% n-propanol.</li> <li>A mixture of 90% water, and 20% non- ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10). A mixture of 90% water, 3-8% ammonium hydroxide or concentrated ammonia, and 2% liquid detergent. Mix equal amounts of the following to total two times the estimated spill volume: (1) mineral spirits 80%, VM&amp;P naptha</li></ol></li></ul>
<ul> <li>Steps to be Taken in Case Material is Released or Spilled Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil. </li> <li>Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape. Additional Spill Procedures/Neutralization/Decontamination solution. 2. A mixture of 75% water, 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10) and 5% n-propanol. 3. A mixture of 80% water, and 20% non- ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10). 4. A mixture of 90% water, 3-8% ammonium hydroxide or concentrated ammonia, and 2% liquid detergent.</li></ul>
<ul> <li>Steps to be Taken in Case Material is Released or Spilled Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil. </li> <li>Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape. Additional Spill Procedures/Neutralization/Decontamination – Neutralization/Decontamination Solutions: <ol> <li>Colorimetric Laboratories Inc. (CLI) decontamination solution.</li> <li>A mixture of 75% water, 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10) and 5% n-propanol.</li> <li>A mixture of 90% water, and 20% non- ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10).</li> <li>A mixture of 90% water, 3-8% ammonium hydroxide or concentrated ammonia, and 2% liquid detergent.</li> <li>Mix equal amounts of the following to total two times the estimated spill volume: (1) mineral spirits 80%, VM&amp;P naptha 15% and household detergent 5%; and (2) a 50/50 mixture of monoethanolamine and water. </li> </ol></li></ul>
<ul> <li>Steps to be Taken in Case Material is Released or Spilled Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil. </li> <li>Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe@ tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape. Additional Spill Procedures/Neutralization/Decontamination – Neutralization/Decontamination Solutions: <ol> <li>Colorimetric Laboratories Inc. (CLI) decontamination solution.</li> <li>A mixture of 75% water, 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10) and 5% n-propanol.</li> <li>A mixture of 80% water, and 20% non- ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10).</li> <li>A mixture of 90% water, 3-8% ammonium hydroxide or concentrated ammonia, and 2% liquid detergent.</li> <li>Mix equal amounts of the following to total two times the estimated spill volume: (1) mineral spirits 80%, VM&amp;P naptha 15% and household detergent 5%; and (2) a 50/50 mixture of monoethanolamine and water. </li> </ol></li></ul>
<ul> <li>Steps to be Taken in Case Material is Released or Spilled Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil. Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape. </li> <li>Additional Spill Procedures/Neutralization/Decontamination – Neutralization/Decontamination Solutions: <ol> <li>Colorimetric Laboratories Inc. (CLI) decontamination solution.</li> <li>A mixture of 75% water, 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10) and 5% n-propanol.</li> <li>A mixture of 90% water, and 20% non- ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10).</li> <li>A mixture of 90% water, 3-8% ammonium hydroxide or concentrated ammonia, and 2% liquid detergent.</li> <li>Mix equal amounts of the following to total two times the estimated spill volume: (1) mineral spirits 80%, VM&amp;P naptha 15% and household detergent 5%; and (2) a 50/50 mixture of monoethanolamine and water.</li> </ol> </li> </ul>
<ul> <li>Steps to be Taken in Case Material is Released or Spilled Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil. </li> <li>Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe@ tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape. Additional Spill Procedures/Neutralization/Decontamination – Neutralization/Decontamination Solutions: <ol> <li>Colorimetric Laboratories Inc. (CLI) decontamination solution.</li> <li>A mixture of 75% water, 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10) and 5% n-propanol.</li> <li>A mixture of 80% water, and 20% non- ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10).</li> <li>A mixture of 90% water, 3-8% ammonium hydroxide or concentrated ammonia, and 2% liquid detergent.</li> <li>Mix equal amounts of the following to total two times the estimated spill volume: (1) mineral spirits 80%, VM&amp;P naptha 15% and household detergent 5%; and (2) a 50/50 mixture of monoethanolamine and water. </li> </ol></li></ul>
<ul> <li>Steps to be Taken in Case Material is Released or Spilled Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil. Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape. </li> <li>Additional Spill Procedures/Neutralization/Decontamination – Neutralization/Decontamination Solutions: <ol> <li>Colorimetric Laboratories Inc. (CLI) decontamination solution.</li> <li>A mixture of 75% water, 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10) and 5% n-propanol.</li> <li>A mixture of 90% water, and 20% non- ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10).</li> <li>A mixture of 90% water, 3-8% ammonium hydroxide or concentrated ammonia, and 2% liquid detergent.</li> <li>Mix equal amounts of the following to total two times the estimated spill volume: (1) mineral spirits 80%, VM&amp;P naptha 15% and household detergent 5%; and (2) a 50/50 mixture of monoethanolamine and water.</li> </ol> </li> </ul>
<ul> <li>Steps to be Taken in Case Material is Released or Spilled Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil. Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape. </li> <li>Additional Spill Procedures/Neutralization/Decontamination – Neutralization/Decontamination Solutions: <ol> <li>Colorimetric Laboratories Inc. (CLI) decontamination solution.</li> <li>A mixture of 75% water, 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10) and 5% n-propanol.</li> <li>A mixture of 90% water, and 20% non- ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10).</li> <li>A mixture of 90% water, 3-8% ammonium hydroxide or concentrated ammonia, and 2% liquid detergent.</li> <li>Mix equal amounts of the following to total two times the estimated spill volume: (1) mineral spirits 80%, VM&amp;P naptha 15% and household detergent 5%; and (2) a 50/50 mixture of monoethanolamine and water.</li> </ol> </li> </ul>
<ul> <li>Steps to be Taken in Case Material is Released or Spilled Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil. Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape. </li> <li> Additional Spill Procedures/Neutralization/Decontamination – Neutralization/Decontamination Solutions:     <ul> <li>Colorimetric Laboratories Inc. (CLI) decontamination solution.</li> <li>A mixture of 75% water, 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10) and 5% n-propanol.</li> <li>A mixture of 90% water, and 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10).</li> <li>A mixture of 90% water, 3-8% ammonium hydroxide or concentrated ammonia, and 2% liquid detergent.</li> <li>Mix equal amounts of the following to total two times the estimated spill volume: (1) mineral spirits 80%, VM&amp;P naptha 15% and household detergent 5%; and (2) a 50/50 mixture of monoethanolamine and water. </li> </ul></li></ul>
<ul> <li>Steps to be Taken in Case Material is Released or Spilled         <ul> <li>Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil.</li> </ul> </li> <li>Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri<sup>TM</sup>, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formulas below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape.</li> <li>Additional Spill Procedures/Neutralization/Decontamination solution.</li> <li>Colorimetric Laboratories Inc. (CLI) decontamination solution.</li> <li>A mixture of 75% water, 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10) and 5% n-propanol.</li> <li>A mixture of 90% water, 3-8% ammonium hydroxide or concentrated ammonia, and 2% liquid detergent.</li> <li>Mix equal amounts of the following to total two times the estimated spill volume: (1) mineral spirits 80%, VM&amp;P naptha 15% and household detergent 5%; and (2) a 50/50 mixture of monoethanolamine and water.</li> <li>Waste Disposal Method</li> <li>Waste disposal should be in accordance with existing federal, state and local environmental control laws. Incineration is the preferred method.</li> <li>Empty Container Precautions:</li> </ul>
<ul> <li>Steps to be Taken in Case Material is Released or Spilled Evacuate non-emergency personnel. Isolate the area and prevent access. Remove ignition sources. Notify management. Put on protective equipment. Control sources of the leak. Ventilate. Contain the spill to prevent spread into drains, sewers, water supplies, or soil. Minor Spills or Leak (Wet Surface): Cover spill area with suitable absorbent material (Kitty Litter, Oil-dri™, etc.). Saturate absorbent material with neutralization solution (see formulas below) and mix. Wait 15 minutes. Collect material in open-head metal containers. Repeat application or decontamination solution (see formula below), with scrubbing, followed by absorbent until the surface is decontaminated. Check for residual surface contamination. Swipe® tests have been used for this purpose. Apply lid loosely and allow containers to vent for 72 hours to let carbon dioxide (CO2) escape. </li> <li>Additional Spill Procedures/Neutralization/Decontamination – Neutralization/Decontamination Solutions: <ol> <li>Colorimetric Laboratories Inc. (CLI) decontamination solution.</li> <li>A mixture of 80% water, and 20% non-ionic surfactant (e.g. Poly-Tergent SL-62, Tegritol TMN-10) and 5% n-propanol.</li> <li>A mixture of 90% water, 3-8% ammonium hydroxide or concentrated ammonia, and 2% liquid detergent.</li> <li>Mix equal amounts of the following to total two times the estimated spill volume: (1) mineral spirits 80%, VM&amp;P naptha 15% and household detergent 5%; and (2) a 50/50 mixture of monoethanolamine and water. </li> </ol></li></ul>

#### Precautions to be Taken in Handling and Storage

Recommended Storage Temperature: Minimum - 25°C (77°F), Maximum - 30°C (86°F)

#### Recommended Storage Period: 6 months maximum

#### Handling and Storage Precautions:

Do not breathe vapors, mists, or dusts. Use adequate ventilation to keep isocyanates levels below the exposure limits. Wear respiratory protection if material is heated, sprayed, used in confined space, or if the exposure limit is exceeded. Warning properties (irritation of the eyes, nose and throat or odor) are not adequate to prevent overexposure from inhalation. This material can produce asthmatic sensitization upon either single inhalation exposure to a relatively high concentration or upon repeated inhalation exposures to lower concentrations. Individuals with lung or breathing problems or prior allergenic reactions to isocyanates must not be exposed to vapor or spray mist. Avoid contact with skin and eyes. Wear appropriate eye and skin protection. Wash thoroughly after handling. Do not breathe smoke and gases created by overheating or burning this material. Decomposition products can be highly toxic and irritating. Store in tightly closed containers to prevent moisture contamination. Do not reseal if contamination is suspected.

#### Further Information on Storage Conditions:

Ideal storage temperature range is dependent on the specific polymer due to viscosity and melting point differences between the polymers. Use 25°C (77°F) to 30°C (86°F) as a guideline to most isocyanates for optimum storage temperature. If some isocyanates are stored at or below a temperature of 25°C (77°F), crystallization and settling of the isocyanate may occur. Storage in a cold warehouse can cause crystals to form. These crystals can settle to the bottom of the container. If crystals form, they can be melted easily with moderate heat. It is suggested that a container the size of a drum be warmed for 16-24 hours at sufficient temperature to melt the crystals. When the crystals are melted, the container should be agitated by rolling or stirring, until the contents are homogenous. Since heated isocyanate will generate vapors more rapidly than products stored at 25°C (77°F), be sure to follow the precautions under the Personal Protection section of the MSDS whenever opening a heated isocyanate container.

#### **Other Precautions:**

Employee education and training in the safe use and handling of this product are required under the OSHA Hazard

Communication Standard found in 29 CFR 1900.1200.

Smoking in areas where this material is used should be strictly prohibited.

When applying this product around air intake vents of buildings, take steps to assure that occupants do not get exposed to vapors or spray of product.

### **\*\*\*Section VIII – Control Measures**\*\*\*

#### **Respiratory Protection**

Airborne isocyanate concentrations greater than the ACGIH TLV-TWA or OSHA PEL-C (PEL) can occur in inadequately ventilated environments when isocyanate is sprayed, aerosolized, or heated. In such cases, respiratory protection must be worn. The type of respiratory protection selected must comply with the requirements set forth in OSHA's Respiratory Protection Standard (29 CFR 1910.134). The type of respiratory protection available includes (1) an atmosphere-supplying respirator such as a self-contained breathing apparatus (SCBA) or supplied air respirator (SAR in the positive pressure or continuous flow mode, or (2) an air-purifying respirator (APR). If an APR is selected then (a) the cartridge must be equipped with an end-of-service life indicator (ESLI) certified by NIOSH, or (b) a change out schedule, based on objective information or data that will ensure that the cartridges are changed out before the end of their service life, must be developed and implemented. The basis for the change out schedule must be described in the written respirator program. Further, if an APR is selected, the airborne diisocyanate concentration must be no greater than 10 times the TLV or PEL. The recommended APR cartridge is an organic vapor/particle filter combination cartridge (OV/P100).

Ventilation

Local exhaust should be used to maintain levels below TLV whenever isocyanate is heated, sprayed, or aerosolized. Standard reference sources regarding industrial ventilation (e.g. ACGIH Industrial Ventilation Manual) should be consulted for guidance about adequate ventilation. To ensure that published exposure limits have not been exceeded, monitoring for airborne diisocyanates should become part of the overall employee exposure characterization program. NIOSH, OSHA, and others have developed sampling and analytical methods.

#### **Protective Gloves**

Gloves should be worn. Nitrile rubber shows excellent resistance. Butyl rubber, neoprene, and PVC are also effective.

#### **Eye Protection**

When directly handling liquid product, eye protection is required. Example of eye protection include a chemical safety goggle, or chemical goggle in combination with a full face shield when there is a greater risk of splash.

#### **Other Protective Clothing or Equipment**

Avoid all skin contact. Depending on the condition of use, cover as much of the exposed skin area as possible with appropriate clothing to prevent skin contact. Use skin barrier cream on exposed skin.

## Work/Hygienic Practices

Employees should wash their hands and face before eating, drinking or using tobacco products. Educate and train employees in the safe use and handling of this product.

#### Note to Reader:

To the best of our knowledge, the information contained herein is accurate. However, neither the above named supplier nor any of its subsidiaries assumes any liability whatsoever for the accuracy or completeness of the information contained herein. Final determination of suitability of any material is the sole responsibility of the user.

U.S. DEF Occupational Sat		MENT OF LA d Health Adr			
MATERIAL	-				
Required under USDL Safet	y and H	Health Regular	ions for Ship Repairi	ng,	
Shipbuilding, and Sh	-			***	
***Section I – Production Manufacturer's Name	i and	i Compan	Emergency Tel		
Master Industries, Inc.			Emergency rei	(714) 660-0644	
Address (Number, Street, City, State, and Zip Code)			Date Issued: 02		
14420 Myford Road, Bldg.150 Irvine, California 92					
Chemical Name and Synonyms	Tra		d Synonyms	D (UCNO (CD 1000	
Aliphatic Hydrocarbons Chemical Filially	For	Kwik-Pl mula	ug No./45//46.HI	RD (HCNO 65D-180S-	TAN B COMP)
	FOL	lliula			
4440 A TT TT TT	T	. 1		4 °	
***Section II – Hazardous	Ingr	edients/S			XX/2-14.0/
Reportable Components			CAS Number	Vapor Pressure mmHg @ Temp	Weight %
Aliphatic Hydrocarbons (Stoddard Type)			8052-41-3	2.00 @ 68.00°F	10-15%
ACGIH TLV: 100ppm (TWA), OSHA PEL: 500ppm (	(TWA	.)		0.000	
*** No toxic chemical(s) subject to the reporting requirement	ts of se	ection 313 c	f Title III and of 4	0 CFR 372 are present	***
California Drongsition (5 Information					
California Proposition 65 Information To the best of our knowledge, this product does not co	ontain	any of the l	sted chemicals w	hich the state of Califo	rnia has found
to cause cancer, birth defects or other reproductive ha		any of the f	isted enemicars, w		Tina nas tound
***Section III –	Phys	sical/Cher	nical Data***		
<b>Boiling Range</b> 400°F			ravity (H2O=1)	0.985	
Vapor Pressure (mm Hg)     Heavier than air.		Evaporat		Slower than et	her.
Coating V.O.C. 0.98 lb/gl		Material	V.O.C.	0.98 lb/gl	
<b>Solubility in Water</b> Slightly soluble in water.					
Appearance and Odor Colored liquid with sweet od	lor.				
***Section IV – Fire	and	Explosio	n Hazard Data	***	
Flash Point (Method Used): 120°F (TCC)Flammable I	Limit	s in Air by	Volume:	Lower: 0.7 U	Jpper: 5.0
Extinguishing Media					
Use dry chemical foam, carbon dioxide, water fog o	or fine	spray. Do r	ot use direct wate	r spray as it will spread	the fire.
Special Fire Fighting Procedures Use positive pressure, self contained breathing appa	notre (	(SCDA) and	matastiva fina fia	hting alothing	
Ose positive pressure, sen contained oreaning appa	Tatus (	SCDA) and	protective file fig	nung ciounng.	
Unusual Fire and Explosion Hazards					
Sealed drums may heat up and explode during a fire	e. Coo	ol with cold	water spray. Mate	rial will burn when exp	posed to
persistent direct flame. "Empty" containers retain re					
DO NOT pressurize, cut, weld, braze, solder, drill, g					
sparks, static electricity, or other sources of ignition					
Empty drums should be completely drained, properl disposed of.	iy bung	geu anu pro	inputy returned to a	a urum reconultioner, 0	i property
Static Discharge: Material can accumulate static cha	arges v	which can ca	use an incendiary	electrical discharge.	
Vapors are heavier than air and may travel across the	-				oack fire danger.
***Section	V – F	Reactivity	Data <sup>***</sup>		
Stability: Stable.					
Conditions to Avoid					
Elevated temperatures.					

Incompatibly (Materials to Avoid)
-----------------------------------

Avoid oxidizing agents, strong acids, and strong bases. Product reacts exothermally with isocyanates.

#### Hazardous Decomposition or Byproducts

Carbon Dioxide (CO2), carbon monoxide (CO), oxides of nitrogen (NOx), dense black smoke, other undetermined compounds.

#### **Hazardous Polymerization**

Will not occur.

## \*\*\*Section VI – Health Hazard Data\*\*\*

WARNING: This product is intended to be used as a two-component system. The mixing of these two components (part A and part B) will have hazards associated with both part A and part B. Refer to the MSDS of each for complete hazard information when working with the mixture.

#### Inhalation Health Risks and Symptoms of Exposure

At ambient temperatures, prolonged exposure may develop sore throat. At elevated temperatures or by aerosol spray, the inhalation risk is increased. Symptoms include difficulty in breathing, and respiratory irritation. Other symptoms include central nervous system depression (dizziness, drowsiness, weakness, fatigue, nausea, headache, unconsciousness).

#### Skin and Eye Contact Health Risks and Symptoms Exposure

**Skin:** Prolonged and repeated skin contact can cause defatting and drying of the skin which may result in skin irritation and dermatitis (rash).

isocyanates can cause discoloration.

Eye: Eye irritation.

### Skin Absorption Health Risks and Symptoms of Exposure

Skin contact: Can dry and defat skin causing cracks, irritation, and dermatitis.

#### Ingestion Health Risks and Symptoms of Exposure

Other signs of overexposure are central nervous system depression (dizziness, drowsiness, weakness, fatigue, nausea, headache, unconsciousness), pain in the abdomen and lower back, acute kidney failure (sudden slowing or stopping of urine production). May cause metabolic acidosis. May be harmful if swallowed. May cause abdominal discomfort, nausea, vomiting and diarrhea. Aspiration into the lungs may occur during ingestion or vomiting, resulting in lung injury.

### Health Hazards (Acute and Chronic)

Acute: Skin and eye irritation.

Chronic: Dermatitis.

Carcinogenicity: NTP

IARC Monographs: No

**OSHA Regulated:** No

# Specific Health Risks

Dermatitis

# Medical Conditions Generally Aggravated by Exposure

Abrasions or cuts on the skin will lead to increased absorption through the skin.

Carcinogen: No

## **Emergency and First Aid Procedures**

**Eye Contact**: In case of contact, immediately flush eyes with plenty of lukewarm water. Get medical attention if irritation develops.

Skin Contact: Wash affected areas with soap and water. Thoroughly clean shoes before reuse. Wash clothing before reuse. Get medical attention if irritation develops or persists.

Inhalation: If inhaled, remove to fresh air. If breathing is difficult, give oxygen. Get medical attention if irritation develops. Ingestion: If ingested, do not induce vomiting unless directed to do so by medical personnel. Get medical attention. Never give anything by mouth to an unconscious person.

# \*\*\*Section VII – Precautions for Safe Handling and Use\*\*\*

Steps to be Taken in Case Material is Released or Spilled

Eliminate ignition sources. Wear appropriate personal protection during cleanup, such as impervious gloves, boots, and coveralls. Material can cause slippery conditions. Dike or dam spilled material and control further spillage, if possible. Cover spill with inert material (e.g. dry sand or earth, silica gel, acid bonder, universal binder, sawdust). Collect and place in appropriately marked, sealable containers for disposal. Wash spill area with soap and water. Take precautionary measures against static Discharge. Ensure electrical continuity by bonding and grounding (earthing) all equipment. Monitor area with combustible gas indicator.

electrostatic charges may be generated during pumping. Electrostatic discharge may cause fire. Ensure electrical continuity by bonding and grounding (earthing) all equipment. Restrict line velocity during pumping in order to avoid generation of electrostatic discharge (<-1m/sec until fill pipe submerged to twice its diameter, then <-7m/sec). Avoid splash filling. Do NOT use compressed air for filling, discharging, or handling operation.

### Waste Disposal Method

This product should not be released into the environment. The product should not be allowed to enter drains, water courses or soil. Recycling is the preferred method for disposing of material. Otherwise, follow all applicable state, federal and local regulations in waster classification, transportation, and disposal. It is the responsibility of the waste generator to do this.

## Precautions to be Taken in Handling and Storage

Recommended Storage Temperature: Keep product below 140°F (60°C).

Handle in accordance with good industrial hygiene and safety practices. Wash thoroughly after handling. Keep container closed when not in use. Material is hygroscopic and may absorb small amounts of atmospheric moisture. Avoid breathing of vapor or mist.

### **Other Precautions:**

If contamination with isocyanates is suspected, do not reseal containers, as pressure may develop and heat buildup and foam production may occur.

## \*\*\*Section VIII – Control Measures\*\*\*

#### **Respiratory Protection**

None required under normal use: Use NIOSH approved air supplied respirator during die cleaning, high temperature processing, air-spray environment or when thermal decomposition is suspected. Formaldehyde generation is possible if temperature exceeds 300°F.

#### Ventilation

General ventilation is all that is required under normal conditions of use. If product is applied or used at elevated temperatures, use exhaust ventilation to keep concentrations at a safe level.

The use of mechanical dilution ventilation is recommended whenever this product is used in a confined space, is heated above ambient temperatures, or is agitated. Use explosion-proof ventilation equipment to keep the concentration of vapors at a safe level.

### **Protective Gloves**

Permeation-resistant gloves such as Butyl rubber gloves and Neoprene gloves should be used to protect the hands from contacting the product.

### **Other Protective Clothing or Equipment**

Wear safety shoes when handling drums.

### Work/Hygienic Practices

Employees should wash their hands and face before eating, drinking or using tobacco products. Educate and train employees in the safe use and handling of this product.

### Note to Reader:

To the best of our knowledge, the information contained herein is accurate. However, neither the above named supplier nor any of its subsidiaries assumes any liability whatsoever for the accuracy or completeness of the information contained herein. Final determination of suitability of any material is the sole responsibility of the user.